



REMOTE CONTROL



Step 4: Use the screwdriver and screws provided to mount the remote board to the back plate



Battery Input

W - Weapon Motor
R - Right Drive Motor
L - Left Drive Motor

